



## ALPINE ACV SERIES

### Alpine Pressure Sustaining / Relief Control Valve IOM Manual



Relief/Sustaining  
Pilot P500

# Installation, Operating and Maintenance Manual – BT116 Sustaining / Relief Valve

**Address:** 272 Bath Street Glasgow G2 4JR **Cell:** +44 (0) 776348 8809: **Land:** +44 (0) 1369 760423:  
**Email:** [john@afcvalves.co.uk](mailto:john@afcvalves.co.uk): **Web:** [www.afcvalves.co.uk](http://www.afcvalves.co.uk)


# Ultra/Alpine Series

## BT116 Sustaining/Relief valve

### LEGEND

- 1 Upstream Ball valve
- 2 Y-Strainer
- 3 Upstream Gauge
- 4 Flow controller
- 5 Pressure Relief Pilot P500
- 6 Downstream Ball valve

**Note** U.C.V. may have an added feature of a bonnet ball valve which when in the closed position freezes the valve in its set position. Enabling work to be done on the control loop without closing the pipe line. This must remain open during normal operations



## FUNCTION : Refer to drawing No 1

This valve has two separate functions depending where it is installed in the main pipeline

- a) If it is installed in an offshoot of the mainline into a storage tank or open – ended. The BT116 is used to relieve excess mainline pressure - as a pressure relief valve
- b) If it installed in the mainline itself. The BT116 is used to the maintain upstream pressure at a set pressure - as a pressure sustaining valve

## CONSIDERATIONS :


- \* If the BT116 is used as a Relief valve, the outlet should be outside the valve chamber to avoid flooding or into a storage tank
- If the BT116 is used as a Relief valve, The pressure setting should be above the dynamic head pressure i.e. with the pumps running

## COMMISSIONING :

- Close the mainline upstream and downstream isolating valves on either side of the control valve
- Set the Flow controller ( No 4 ) to the halfway position ( Clockwise closing )
- Make sure the upstream ball valve ( No1 ) is in the open position
- Close the downstream ball valve ( No 6 )
- Slowly open the mainline upstream isolating valve
- Bleed off all the accumulated air trapped inside the bonnet by loosening one of the gland nuts at the highest point on the valve
- Open the downstream mainline isolating valve. The valve should remain in the closed position
- **RELIEF SETTING** Turn the adjustment screw of the P500 relief pilot ( No 5 ) all the way in ( clockwise )
- Open the downstream ball valve ( No 6 ) The valve should remain closed
- If the line has pumps start the pumps
- Slowly turn the P500 adjustment screw out ( anti-Clockwise ) until the valve starts opening, then turn the P500 adjustment screw back in one full turn. The valve is now set
- **SUSTAINING SETTING** Turn the P500 (No 5 ) adjustment screw all the way out (anti-clockwise )
- Slowly open the downstream ball valve( No 6 ). The valve should open
- While monitoring the Upstream Pressure gauge turn the P500 Pilot adjustment screw in ( Clockwise ) keep turning it in until the sustaining upstream pressure is achieved

NOTE : Ball valve operation..... Closing the Upstream ball valve No1 will open the main valve  
Closing the downstream ball valve No 6 will close the main valve

Drawing No 2



PARTS LIST - SPECIFICATIONS

No	Description	Material	Standard
1	Body	Ductile Iron	GJS 500 – 7
2	Seat	Stainless Steel	AISI 304 / 316
3	O-ring	Rubber	NBR
4	O-ring	Rubber	NBR
5	Bolt	Stainless Steel	A2 / A4
6	Washer	Stainless Steel	A2 / A4
7	Bonnet	Ductile Iron	GJS 500 – 7
8	Bush	Bronze	C61900
9	Spring	Stainless Steel	AISI 304 / 316
10	Caulking Nut	Stainless Steel	A4
11	Diaphragm	Nylon Reinforced Rubber	EPDM + Nylon Fabric
12	Fixing Holder	Ductile Iron	GJS 500 – 7
13	Disc Holder	Ductile Iron	GJS 500 – 7
14	Seal	Rubber	EPDM
15	Seal Retainer	Stainless Steel	AISI 304 / 316
16	Stem	Stainless Steel	AISI 304 / 316
17	Plug	Stainless Steel	AISI 304 / 316
18	Screw	Stainless Steel	A2 / A4
19	Plug	Stainless Steel	A2 / A4
20	Washer	Stainless Steel	A2 / A4

## **MAINTENANCE ( Refer Drawing No 2 )**

The Ultra Sustaining Relief needs periodic maintenance of 1 – 2 years depending on the severity of operating conditions

N.B. Make sure there is no pressure In or directly upstream of the valve - Use the mainline isolating valves to ensure personnel safety

- Check the tightness of the Control Loop fittings
- Check the flanges for leaks
- Remove the bonnet and check the diaphragm ( 11 ) for Rips or damage
- Lift the diaphragm assembly out
- Check the O Rings ( 3 & 4 ) and seal ( 14 )
- Check the Disc Holder ( 13 ) for cavitation wear

## **TROUBLE SHOOTING GUIDE**

### Valve refuses to open

- Stem Jammed or blockage on top of stem
- Blockage on the downstream Control Loop
- Leak on the upstream Control Loop
- Diaphragm torn
- Downstream ball valve closed
- Relief Pilot blocked or damaged
- Low upstream pressure

### Valve Refuses to close

- \* Debris underneath the stem
- Blockage on the upstream Control Loop
- Leak on the downstream Control Loop
- Torn Diaphragm
- Upstream ball valve closed